

Instruction for CHW Ag/Anaplasma Ab/E.canis Ab/Lyme Ab test



Sample fill line (black line) : 1 drop (10 µl)

1

Sampling
& loading



1 drop of sample

****Do not overload the sample !!**

2

Absorption



Wait for complete absorption

3

Buffer addition



2 drops of buffer

****after complete absorption**

4

Reading

00:05:00~00:10:00



+

Read the result 10 min

-

5

Discard

00:10:00



**Discard the used device
In valid result after 10 min**

